

|    | A                            | B                                    | C  | D     | E  | F  | G          |
|----|------------------------------|--------------------------------------|--|-------|----|----|------------|
| 1  | GG nr                        | OEM nr                               | Printer Models   | Sider |    | Pk |            |
| 2  | HP                           |                                      |  |       |    |    |            |
| 3  | NT-C2612<br>(Cartridge 703)  | HP Q2612A /<br>Cartridge 703         | HP LaserJet 1010/1012/1015   | 2000  | BK | 12 | <b>NEW</b> |
| 4  | NT-C2612X<br>(Cartridge 703) | HP Q2612X                            | HP LaserJet 1010/1012/1015   | 2500  | BK | 12 | <b>NEW</b> |
| 5  | NT-C6511C                    | HP Q6511A                            | HP LaserJet 2410/2420/2420d/2420dn/2430tn/2430dtn<br>Canon LBP-3460                                    | 6000  | BK | 3  | <b>NEW</b> |
| 6  | NT-C6511XC                   | HP Q6511X                            | HP LaserJet 2410/2420/2420d/2420dn/2430tn/2430dtn<br>Canon LBP-3460                                    | 12000 | BK | 3  | <b>NEW</b> |
| 7  | NT-C7551C                    | HP Q7551A                            | HP P3005/P3005D/P3005N   | 6500  | BK | 3  | <b>NEW</b> |
| 8  | NT-C7551XC                   | HP Q7551X                            | HP P3005/P3005D/P3005N   | 13000 | BK | 3  | <b>NEW</b> |
| 9  | NT-C7516XC                   | HP Q7516A                            | HP LaserJet 5200   | 12000 | BK | 3  | <b>NEW</b> |
| 10 | NT-C0435C                    | HP CB435A                            | HP LaserJet P1005 / P1006  | 1500  | BK | 12 | <b>NEW</b> |
| 11 | NT-C0436C                    | HP CB436A                            | HP LaserJet P1505 / P1505n / M1120 / M1522n / M1522nf  | 2000  | BK | 12 | <b>NEW</b> |
| 12 | NT-C0505C                    | HP CE505A                            | HP Laserjet P2035/P2035n,P2055D/2055DN/2055X   | 2300  | BK | 6  | <b>NEW</b> |
| 13 | NT-C0505XC                   | HP CE505X                            | HP Laserjet P2055D/2055DN/2055X  | 6500  | BK | 6  | <b>NEW</b> |
| 14 | NT-C0364C                    | HP CC364A                            | HP Laserjet P4014 /P4015N/P4015X/P4515N/P4515X   | 10000 | BK | 3  | <b>NEW</b> |
| 15 | NT-C0364XC                   | HP CC364X                            | HP Laserjet P4015N/P4015X/P4515N/P4515X  | 24000 | BK | 3  | <b>NEW</b> |
| 16 | NT-CH390C                    | HP CE390A                            | HP LaserJet Enterprise M4555h<br>MFP/4555MFP/4555F/4555 FSKM   | 10000 | BK | 3  | <b>New</b> |
| 17 | NT-CH390XC                   | HP CE390X                            | HP LaserJet Enterprise M4555h<br>MFP/4555MFP/4555F/4555 FSKM   | 24000 | BK | 3  | <b>New</b> |
| 18 | NT-C0278C                    | HP CE278A <b>Ca-<br/>non CRG 726</b> | HP Laserjet P1606dn / P1566 / P1560 / M1322 <b>Canon i-<br/>SENSYS LBP6200D</b>                        | 2100  | BK | 12 | <b>NEW</b> |
| 19 | NT-C0285C                    | HP CE285A <b>Ca-<br/>non CRG-725</b> | HP Laserjet P1102w / M1130 / M1136 / M1210 /<br>M1213nf / M1212NF;Canon i-SENSYS LBP6000               | 1600  | BK | 12 | <b>NEW</b> |
| 20 | NT-CH540BK                   | HP CB540A /<br>Canon 716 BK          | HP Color Laserjet<br>CP1210/CP1215/CP1515N/CP1518ni/CM1312/CM1510/C<br>M1300<br>Canon LBP5050/LBP5050n | 2200  | BK | 12 | <b>NEW</b> |
| 21 | NT-CH541C                    | HP CB541A /<br>Canon 716C            | HP Color Laserjet<br>CP1210/CP1215/CP1515N/CP1518ni/CM1312/CM1510/C<br>M1300<br>Canon LBP5050/LBP5050n | 1400  | C  | 12 | <b>NEW</b> |
| 22 | NT-CH542Y                    | HP CB542A /<br>Canon 716Y            | HP Color Laserjet<br>CP1210/CP1215/CP1515N/CP1518ni/CM1312/CM1510/C<br>M1300<br>Canon LBP5050/LBP5050n | 1400  | Y  | 12 | <b>NEW</b> |
| 23 | NT-CH543M                    | HP CB543A /<br>Canon 716M            | HP Color Laserjet<br>CP1210/CP1215/CP1515N/CP1518ni/CM1312/CM1510/C<br>M1300<br>Canon LBP5050/LBP5050n | 1400  | M  | 12 | <b>NEW</b> |
| 24 | NT-CH530BK                   | HP CB530A Ca-<br>non 718bk           | HP Color Laser CP2020/CP2025   | 3.500 | BK | 6  | <b>NEW</b> |
| 25 | NT-CH531C                    | HP CB531A Ca-<br>non 718c            | HP Color Laser CM2320/2323/2430  | 2.800 | C  | 6  | <b>NEW</b> |
| 26 | NT-CH532Y                    | HP CB532A Ca-<br>non 718Y            | HP Color Laser CM-2320, 2323, 2430   | 2.800 | Y  | 6  | <b>NEW</b> |
| 27 | NT-CH533M                    | HP CB533A Ca-<br>non 718M            | HP Color Laser CM-2320, 2323, 2430   | 2.800 | M  | 6  | <b>NEW</b> |
| 28 | <b>NT-CH250XBK</b>           | HP CE250A/X                          | HP LaserJet CP3525, CP3525N, CP3525DN, CP3525X,<br>CM3530, CM3530fs , <b>Canon LBP-7700C</b>           | 10500 | BK | 6  | <b>NEW</b> |
| 29 | <b>NT-CH251C</b>             | HP CE251A                            | HP LaserJet CP3525, CP3525N, CP3525DN, CP3525X,<br>CM3530, CM3530fs <b>Canon LBP-7700C</b>             | 7000  | C  | 6  | <b>NEW</b> |
| 30 | <b>NT-CH252Y</b>             | HP CE252A                            | HP LaserJet CP3525, CP3525N, CP3525DN, CP3525X,<br>CM3530, CM3530fs , <b>Canon LBP-7700C</b>           | 7000  | Y  | 6  | <b>NEW</b> |
| 31 | <b>NT-CH253M</b>             | HP CE253A                            | HP LaserJet CP3525, CP3525N, CP3525DN, CP3525X,<br>CM3530, CM3530fs , <b>Canon LBP-7700C</b>           | 7000  | M  | 6  | <b>NEW</b> |

|    | A           | B          | C   | D     | E  | F  | G          |
|----|-------------|------------|---|-------|----|----|------------|
| 1  | GG nr       | OEM nr     | Printer Models  | Sider |    | Pk |            |
| 32 | NT-CH260 BK | HP CE 260A | HP Color Laserjet CP4025 Series /CP4525 Series                | 8500  | BK | 6  | <b>NEW</b> |
| 33 | NT-CH261 C  | HP CE 261A | HP Color Laserjet CP4025 Series /CP4525 Series                | 11000 | C  | 6  | <b>NEW</b> |
| 34 | NT-CH262 Y  | HP CE 262A | HP Color Laserjet CP4025 Series /CP4525 Series                | 11000 | Y  | 6  | <b>NEW</b> |
| 35 | NT-CH263 M  | HP CE 263A | HP Color Laserjet CP4025 Series /CP4525 Series                | 11000 | M  | 6  | <b>NEW</b> |
| 36 | NT-CH320BK  | HP CE320   | HP Laserjet Pro<br>CP1525N, CP1525NW, CM1415FN, CM1415FNW MFP | 2000  | BK | 12 | <b>NEW</b> |
| 37 | NT-CH321C   | HP CE321   | HP Laserjet Pro<br>CP1525N/CP1525NW/CM1415FN/CM1415FNW MFP    | 1300  | C  | 12 | <b>NEW</b> |
| 38 | NT-CH322Y   | HP CE322   | HP Laserjet Pro<br>CP1525N/CP1525NW/CM1415FN/CM1415FNW MFP    | 1300  | Y  | 12 | <b>NEW</b> |
| 39 | NT-CH323M   | HP CE323   | HP Laserjet Pro<br>CP1525N/CP1525NW/CM1415FN/CM1415FNW MFP    | 1300  | M  | 12 | <b>NEW</b> |
| 40 | NT-CH310B   | HP CE310A  | HP LaserJet Pro CP1025nw color printer                        | 1200  | BK | 16 | <b>NEW</b> |
| 41 | NT-CH311C   | HP CE311A  | HP LaserJet Pro CP1025nw color printer                        | 1000  | C  | 16 | <b>NEW</b> |
| 42 | NT-CH312Y   | HP CE312A  | HP LaserJet Pro CP1025nw color printer                        | 1000  | Y  | 16 | <b>NEW</b> |
| 43 | NT-CH313M   | HP CE313A  | HP LaserJet Pro CP1025nw color printer                        | 1000  | M  | 16 | <b>NEW</b> |

|    | A                                     | B   | C   | D     | E  | F  | G          |
|----|---------------------------------------|---|---|-------|----|----|------------|
| 1  | GG nr                                 | OEM nr  | Printer Models  | Sider |    | Pk |            |
| 44 |                                       |   | <b>Samsung</b>  |       |    |    |            |
| 45 | NT-P1710U<br>(SCX4100, 4216,<br>X215) | Samsung<br>ML1710, 4216,<br>4100, X215,<br>3115, PE16     | Samsung ML- 1500/1510/1510b/1520/1710/1710B<br>/1710D/1710P/1740/1750/1755/SF-560/565P<br>Samsung ML-SCX4016/4100/4116/4116D/4216F<br>Xerox Phaser 3115/3120/3121/3130/3116<br><del>Xerox WorkCentre PE16 Lexmark X215 MFP Ricoh FX16</del> | 3000  | BK | 6  | <b>NEW</b> |
| 46 | NT-C1210U (U-<br>niversal)            | Samsung SF-<br>5100 L1210 Lex<br>E210                     | Samsung ML-1010/1020M/1210/1220M/1250/1430<br>/4500/4600 Samsung ML-808 Lexmark E210<br>Samsung SF-515/530/531P/535e/5100/5100P/555P<br>Samsung MSYS-5100P Xerox Phaser3110/3210  | 2500  | BK | 6  | <b>NEW</b> |
| 47 | NT-C1610 (U-<br>niversal)             | Samsung<br>ML1610<br>ML2010<br>SCX4521D3<br>GC502         | Samsung ML-1610\2010 Samsung SCX-4521F\4321 Dell la-<br>ser printer 1100 Samsung ML-2570 ,ML-2571 ,ML-2510<br>and ML-2015 /xerox 3117   | 2000  | BK | 6  | <b>NEW</b> |
| 48 | NT-C1610X (U-<br>niversal)            | Samsung ML-<br>1610 /ML-<br>2010 / SCX-<br>4521D3 / GC502 | Samsung ML-1610\2010 Samsung SCX-4521F\4321 Dell la-<br>ser printer 1100 Samsung ML-2570 ,ML-2571 ,ML-2510<br>and ML-2015 /xerox 3117   | 3000  | BK | 6  | <b>NEW</b> |
| 49 | NT-C2250XCP                           | Samsung ML-<br>2250D5                                     | Samsung ML-2250/2251N/2251W/2251NP  | 5000  | BK | 6  | <b>NEW</b> |
| 50 | NT-C4720XCP                           | Samsung SCX-<br>4720D3/SCX-<br>4720D5                     | Samsung SCX-4720F/SCX-4520  | 5000  | BK | 6  | <b>NEW</b> |
| 51 | NT-C2550                              | Samsung ML-<br>2550                                       | Samsung ML-2150/2151W/2152W,Samsung ML-<br>2550/2551N/2552W   | 10000 | BK | 6  | <b>NEW</b> |
| 52 | NT-P4200CP                            | Samsung<br>SCXD4200A                                      | Samsung SCX-4200  | 3000  | BK | 6  | <b>NEW</b> |
| 53 | NT-P0300BK                            | Samsung CLP-<br>K300A                                     | Samsung CLP-300/CLP-300N  | 2000  | BK | 32 | <b>NEW</b> |
| 54 | NT-P0300C                             | Samsung CLP-<br>C300A                                     | Samsung CLP-300/CLP-300N  | 1000  | C  | 50 | <b>NEW</b> |
| 55 | NT-P0300M                             | Samsung CLP-<br>M300A                                     | Samsung CLP-300/CLP-300N  | 1000  | M  | 50 | <b>NEW</b> |
| 56 | NT-P0300Y                             | Samsung CLP-<br>Y300A                                     | Samsung CLP-300/CLP-300N  | 1000  | Y  | 50 | <b>NEW</b> |
| 57 | NT-P0350K                             | Samsung CLP-<br>K350A                                     | Samsung CLP-350/351K  | 4000  | BK | 24 | <b>NEW</b> |
| 58 | NT-P0350C                             | Samsung CLP-<br>C350A                                     | Samsung CLP-350/351K  | 2000  | C  | 24 | <b>NEW</b> |
| 59 | NT-P0350M                             | Samsung CLP-<br>M350A                                     | Samsung CLP-350/351K  | 2000  | M  | 24 | <b>NEW</b> |
| 60 | NT-P0350Y                             | Samsung CLP-<br>Y350A                                     | Samsung CLP-350/351K  | 2000  | Y  | 24 | <b>NEW</b> |
| 61 | NT-P0409BK (CLP310)                   | Samsung CLT-<br>K4092S                                    | Samsung CLP-310N/CLP-315 , CLX-3175FN/CLX-3170  | 1500  | BK | 6  | <b>NEW</b> |
| 62 | NT-P0409C (CLP310)                    | Samsung CLT-<br>C4092S                                    | Samsung CLP-310N/CLP-315 , CLX-3175FN/CLX-3170  | 1000  | C  | 6  | <b>NEW</b> |
| 63 | NT-P0409M (CLP310)                    | Samsung CLT-<br>M4092S                                    | Samsung CLP-310N/CLP-315 , CLX-3175FN/CLX-3170  | 1000  | M  | 6  | <b>NEW</b> |
| 64 | NT-P0409Y (CLP310)                    | Samsung CLT-<br>Y4092S                                    | Samsung CLP-310N/CLP-315 , CLX-3175FN/CLX-3170  | 1000  | Y  | 6  | <b>NEW</b> |
| 65 | NT-CS4072BK                           | Samsung CLT-<br>K4072S                                    | Samsung CLP-320/325/W CLX-3185  | 1500  | BK | 6  | <b>NEW</b> |
| 66 | NT-CS4072C                            | Samsung CLT-<br>C4072S                                    | Samsung CLP-320/325/W CLX-3185  | 1000  | C  | 6  | <b>NEW</b> |
| 67 | NT-CS4072M                            | Samsung CLT-<br>M4072S                                    | Samsung CLP-320/325/W CLX-3185  | 1000  | M  | 6  | <b>NEW</b> |
| 68 | NT-CS4072Y                            | Samsung CLT-<br>Y4072S                                    | Samsung CLP-320/325/W CLX-3185  | 1000  | Y  | 6  | <b>NEW</b> |
| 69 | NT-C3050X                             | Samsung ML-<br>D3050B                                     | Samsung ML-3050/3051/3051DN   | 8000  | BK | 6  | <b>NEW</b> |

|    | A            | B                          | C  | D     | E  | F | G   |
|----|--------------|----------------------------|--|-------|----|---|-----|
| 1  | GG nr        | OEM nr                     | Printer Models   | Sider | Pk |   |     |
| 70 | NT-CS3310XC  | Samsung MLT-D2052L         | Samsung ML-3310ND/ML-3710ND, ML-3312ND/ML3312DW/ML-3712ND, SCX-5639FR/SCX-5739FW/SCX-4835FD/SCX-4835FR,SCX-5637FR /SCX-5737Fw,SCX-4833F              | 5000  | BK | 6 | NEW |
| 71 | NT-CS3310XXC | Samsung MLT-D205E          | Samsung ML-3712DW, ML-3712ND, ML-3310ND, ML-3710ND,SCX-5639FR, SCX-5639FW, SCX-5637FN, SCX-5737FN, SCX-5637ER, SCX-5737Fw                            | 10000 | BK | 6 | NEW |
| 72 | NT-C5530X    | Samsung SCX-D5530B         | Samsung SCX-5530FN(SCX-5330)   | 8000  | BK | 6 | NEW |
| 73 | NT-C4725C    | Samsung SCX-D4725A         | Samsung SCX-4725F  | 3000  | BK | 6 | NEW |
| 74 | NT-C1630C    | Samsung ML-D1630A          | Samsung ML1630/1631K,SCX-4500/4501K  | 2000  | BK | 6 | NEW |
| 75 | NT-C3470XC   | Samsung ML-D3470B          | Samsung ML-3470D/ML-3471ND/ML3472NDK   | 10000 | BK | 6 | NEW |
| 76 | NT-P560RC    | Samsung SF-D560RA          | Samsung SF-560R/SF-560RC/SF-565PR/SF-565PRC  | 3000  | BK | 6 | NEW |
| 77 | NT-C1640C    | Samsung MLT-D1082S         | Samsung ML-1640/2240/2241  | 1500  | BK | 6 | NEW |
| 78 | NT-C2850C    | Samsung ML-D2850A          | Samsung ML-2850D/2851ND  | 2000  | BK | 6 | NEW |
| 79 | NT-C2850XC   | Samsung ML-D2850B          | Samsung ML-2850D/2851ND  | 5000  | BK | 6 | NEW |
| 80 | NT-P4300C    | Samsung MLT-D1092S(Europe) | Samsung SCX 4300   | 2000  | BK | 6 | NEW |
| 81 | NT-CS4828XC  | Samsung MLT-D2092S/L       | Samsung SCX-4825FN/SCX-4826FN/SCX-4828FN/SCX-4824HN/ML-2855ND  | 5000  | BK | 6 | NEW |
| 82 | NT-CS5635C   | Samsung MLT-D2082S/ELS     | Samsung ML-3475ND/SCX-5635FN/SCX-5835FN  | 4000  | BK | 6 | NEW |
| 83 | NT-CS5635XC  | Samsung MLT-D2082L/ELS     | Samsung ML-3475ND/SCX-5635FN/SCX-5835FN  | 10000 | BK | 6 | NEW |
| 84 | NT-PS1910C   | Samsung MLT-D1052S         | Samsung ML-1910/1910K/1915/1915K/1916K/2525K/2582K/2525/2525W/2580N/SCX-4600/4600K/4605K/4610K/4623K/4623F/4623FN/SF-650/ML-1911/2526/2581N/SCX-4601 | 1500  | BK | 6 | NEW |
| 85 | NT-PS1910XC  | Samsung MLT-D1052L         | SamsungML-1910/1910K/1915/1915K/1916K/2525K/2582K/2525/2525W/2580N/SCX-4600/4600K/4605K/4610K/4623K/4623F/4623FN/SF-650/ML-1911/2526/2581N/SCX-4601  | 2500  | BK | 6 | NEW |
| 86 | NT-CS1660C   | Samsung MLT-D1042S         | Samsung ML-1660/1665/1660K/1665K/1661K/1670/1675/SCX-3200/3217/3205/3210   | 1500  | BK | 6 | NEW |
| 87 | NT-PS2950C   | SamsungMLT-D103S           | Samsung ML-2950ND/ML-2955ND/ML-2955DW/SCX-4728FD/SCX-4729FD/SCX-4729FW/ML-2951ND/ML-2951D/ML-2955ND/ML-2956ND/Samsung SCX-4729HD/XIL/SCX-4728HN/XIL  | 1500  | BK | 6 | NEW |
| 88 | NT-PS2950XC  | Samsung MLT-D103L          | Samsung ML-2950ND/ML-2955ND/ML-2955DW/SCX-4728FD/SCX-4729FD/SCX-4729FW/ML-2951ND/ML-2951D/ML-2955ND/ML-2956ND/Samsung SCX-4729HD/XIL/SCX-4728HN/XIL  | 2500  | BK | 6 | NEW |

|     | A                                | B   | C  | D     | E  | F  | G          |
|-----|----------------------------------|---|--|-------|----|----|------------|
| 1   | GG nr                            | OEM nr  | Printer Models   | Sider |    | Pk |            |
| 89  |                                  |   | <b>Brother</b>   |       |    |    |            |
| 90  | NT-F0250 (TN200, 300, 8000)      | Brother TN-200 TN-250 TN-300 TN-5000 TN-8050 TN-8000 TN-10J | Brother DCP-1000 /FAX 2800/2900/3800 Brother MFC 4800/6800/9500/9550   | 2500  | BK | 30 | <b>NEW</b> |
| 91  | NT-CB350 (TN2000)                | Brother TN2000/TN350/TN2075/TN-2025/TN-2050                 | Brother DCP 7020/7010/7025<br>Brother FAX 2820/2920<br>Brother HL 2030/2040/2070N/2045/2075N<br>Brother MFC 7220/7225N/7420/7820N<br>Lenovo LJ 2000/M7020/M3120  | 2500  | BK | 6  | <b>NEW</b> |
| 92  | NT-C0580U (TN3170 TN3060 TN7600) | Brother TN-3170/TN-3130/TN-3060/TN-3030/TN-7600/TN-7300     | Brother MFC-8420/8820D/8820DN Brother HL-1650/1670N/1850/1870N/5030/5040 /5050/5070N Brother DCP-8020/8025D Brother MFC-8220/8440/8840D/8840DN Brother DCP-8040/8045D Brother HL-5140/5150D/5150DLT/5170DN/5130/5240/5250DN/5250DNT/5280DW | 7000  | BK | 6  | <b>NEW</b> |
| 93  | NT-P0330 (TN2110)                | Brother TN2110  | Brother HL-2140/2150N/2170W / MFC-7840W/7440N  | 1500  | BK | 6  | <b>NEW</b> |
| 94  | NT-P0360 (TN2120)                | Brother TN2120  | Brother HL-2140/2150N/2170W / MFC-7840W/7440N  | 2600  | BK | 6  | <b>NEW</b> |
| 95  | NT-P2005 (TN2005/ 2085)          | Brother TN2005  | Brother HL-2035 / HL-2035R / HL-2037   | 1500  | BK | 6  | <b>NEW</b> |
| 96  | NT-P0620 (TN3230)                | Brother TN3230  | Brother HL-5340D/5350DN/5370DW/5380DN;DCP-8050DN/8080DN/8380DN/8480DN  | 3000  | BK | 6  | <b>NEW</b> |
| 97  | NT-CB650 (TN3280)                | Brother TN3280  | Brother HL-5340D/5350DN/5370DW/5380DN;DCP-8050DN/8080DN/8380DN/8480DN  | 8000  | BK | 6  | <b>NEW</b> |
| 98  | NT- PB420                        | Brother TN2210  | Brother HL-2240/2240D/2250DN/2270DW/MFC-7360/MFC-7460DN/MFC-7860D/DCP-7060/DCP-7065DN  | 1200  | BK | 6  | <b>NEW</b> |
| 99  | NT- PB450                        | Brother TN2220/TN2010                                       | Brother HL-2240/2240D/2250DN/2270DW/MFC-7360/MFC-7460DN/MFC-7860D/DCP-7060/DCP-7065DN  | 2600  | BK | 6  | <b>NEW</b> |
| 100 | NT-CB210BK (TN230BK)             | Brother TN-230BK  | Brother HL-3040CN, HL-3070CW; MFC-9010CN, MFC-9120CW and the MFC-9320CW  | 2200  | BK | 6  | <b>NEW</b> |
| 101 | NT-CB210C (TN230C)               | Brother TN-230C   | Brother HL-3040CN, HL-3070CW; MFC-9010CN, MFC-9120CW and the MFC-9320CW  | 1400  | C  | 6  | <b>NEW</b> |
| 102 | NT-CB210M (TN230M)               | Brother TN-230M   | Brother HL-3040CN, HL-3070CW; MFC-9010CN, MFC-9120CW and the MFC-9320CW  | 1400  | M  | 6  | <b>NEW</b> |
| 103 | NT-CB210Y (TN230Y)               | Brother TN-230Y   | Brother HL-3040CN, HL-3070CW; MFC-9010CN, MFC-9120CW and the MFC-9320CW  | 1400  | Y  | 6  | <b>NEW</b> |

|     | A           | B                                 | C   | D     | E  | F  | G   |
|-----|-------------|-----------------------------------|---|-------|----|----|-----|
| 1   | GG nr       | OEM nr                            | Printer Models  | Sider |    | Pk |     |
| 104 |             |                                   | <b>XEROX</b>  |       |    |    |     |
| 105 | NT-CX120XC  | Xerox<br>013R00601/109<br>R006006 | Xerox WorkCentre PE120  | 5000  | BK | 6  | NEW |
| 106 | NT-C3150X   | Xerox<br>109R00746/109<br>R00747  | Xerox Phaser 3150   | 5000  | BK | 6  | NEW |
| 107 | NT-CXP220U  | Xerox<br>013R00621                | Xerox 3117/PE220 Samsung ML-1610 Samsung SCX-4521F/4321 DELL LASER PRINTER 1100 | 3000  | BK | 6  | NEW |
| 108 | NT-C3420    | Xerox<br>106R01034                | Xerox 3420/3450   | 10000 | BK | 6  | NEW |
| 109 | NT-C3428XC  | Xerox<br>CWAA0716                 | Xerox phaser 3428   | 8000  | BK | 6  | NEW |
| 110 | NT-P3119C   | Xerox<br>013R00625                | Xerox WorkCentre 3119   | 3000  | BK | 6  | NEW |
| 111 | NT-C3200C   | Xerox<br>113R00730                | Xerox Phaser 3200MFPB/N   | 3000  | BK | 6  | NEW |
| 112 | NT-C3250C   | Xerox<br>106R01373                | Xerox phaser 3250   | 3500  | BK | 6  | NEW |
| 113 | NT-C3250XC  | Xerox<br>106R01374                | Xerox phaser 3250   | 5000  | BK | 6  | NEW |
| 114 | NT-C3300C   | Xerox<br>106R01411                | Xerox Phaser 3300MPF  | 4000  | BK | 6  | NEW |
| 115 | NT-C3300XC  | Xerox<br>106R01412                | Xerox Phaser 3300MPF  | 8000  | BK | 6  | NEW |
| 116 | NT-C3435C   | Xerox<br>106R01414                | Xerox phaser 3435   | 4000  | BK | 6  | NEW |
| 117 | NT-C3435XC  | Xerox<br>106R01415                | Xerox phaser 3435   | 10000 | BK | 6  | NEW |
| 118 | NT-PX3140C  | Xerox<br>108R00908                | Xerox phaser 3140/3155/3160   | 1500  | BK | 6  | NEW |
| 119 | NT-PX3140XC | Xerox<br>108R00909                | Xerox phaser 3140/3155/3160   | 2500  | BK | 6  | NEW |
| 120 | NT-CX3210C  | 106R01485                         | XEROX WorkCentre 3210/3220  | 2000  | BK | 6  | NEW |
| 121 | NT-CX3210XC | 106R01486                         | XEROX WorkCentre 3210/3220  | 4100  | BK | 6  | NEW |
| 122 | NT-C6110BK  | Xerox<br>106R0127/4               | Xerox Phaser 6110/6110MFP   | 2000  | BK | 32 | NEW |
| 123 | NT-C6110C   | Xerox<br>106R01271                | Xerox Phaser 6110/6110MFP   | 1000  | C  | 50 | NEW |
| 124 | NT-C6110M   | Xerox<br>106R01272                | Xerox Phaser 6110/6110MFP   | 1000  | M  | 50 | NEW |
| 125 | NT-C6110Y   | Xerox<br>106R01273                | Xerox Phaser 6110/6110MFP   | 1000  | Y  | 50 | NEW |
| 126 | NT-C6125BK  | Xerox<br>106R01334/106<br>R01338  | Xerox Phaser 6125 Color Laser Printer   | 2000  | BK | 18 | NEW |
| 127 | NT-C6125C   | Xerox<br>106R01331/106<br>R01335  | Xerox Phaser 6125 Color Laser Printer   | 1000  | C  | 18 | NEW |
| 128 | NT-C6125M   | Xerox<br>106R01332/106<br>R01336  | Xerox Phaser 6125 Color Laser Printer   | 1000  | M  | 18 | NEW |
| 129 | NT-C6125Y   | Xerox<br>106R01333/106<br>R01337  | Xerox Phaser 6125 Color Laser Printer   | 1000  | Y  | 18 | NEW |
| 130 | NT-C6130BK  | Xerox<br>106R01278                | Xerox Phaser 6130 Color Laser Printer   | 2500  | BK | 18 | NEW |
| 131 | NT-C6130C   | Xerox<br>106R01279                | Xerox Phaser 6130 Color Laser Printer   | 1900  | C  | 18 | NEW |
| 132 | NT-C6130M   | Xerox<br>106R01280                | Xerox Phaser 6130 Color Laser Printer   | 1900  | M  | 18 | NEW |

|     | A            | B                      | C   | D     | E  | F  | G   |
|-----|--------------|------------------------|---|-------|----|----|-----|
| 1   | GG nr        | OEM nr                 | Printer Models  | Sider |    | Pk |     |
| 133 | NT-C6130Y    | Xerox<br>106R01281     | Xerox Phaser 6130 Color Laser Printer                   | 1900  | Y  | 18 | NEW |
| 134 | NT-C6140BK   | Xerox<br>106R01480     | Xerox Phaser 6140                                       | 2600  | BK | 18 | NEW |
| 135 | NT-C6140C    | Xerox<br>106R01477     | Xerox Phaser 6140                                       | 2000  | C  | 18 | NEW |
| 136 | NT-C6140M    | Xerox<br>106R01478     | Xerox Phaser 6140                                       | 2000  | M  | 18 | NEW |
| 137 | NT-C6140Y    | Xerox<br>106R01479     | Xerox Phaser 6140                                       | 2000  | Y  | 18 | NEW |
| 138 | NT-C6128BK   | Xerox<br>106R01455     | XEROX Phaser 6128MFP color laser Printer                | 3100  | BK | 18 | NEW |
| 139 | NT-C6128C    | Xerox<br>106R01452     | XEROX Phaser 6128MFP color laser Printer                | 2500  | C  | 18 | NEW |
| 140 | NT-C6128M    | Xerox<br>106R01453     | XEROX Phaser 6128MFP color laser Printer                | 2500  | M  | 18 | NEW |
| 141 | NT-C6128Y    | Xerox<br>106R01454     | XEROX Phaser 6128MFP color laser Printer                | 2500  | Y  | 18 | NEW |
| 142 | NT-C6180XBK  | Xerox 113R<br>00726 BK | Xerox Phaser 6180/6180MFP                               | 8000  | BK | 6  | NEW |
| 143 | NT-C6180XC   | Xerox 113R<br>00723 C  | Xerox Phaser 6180/6180MFP                               | 6000  | C  | 6  | NEW |
| 144 | NT-C6180XM   | Xerox 113R<br>00724 M  | Xerox Phaser 6180/6180MFP                               | 6000  | M  | 6  | NEW |
| 145 | NT-C6180XY   | Xerox 113R<br>00725 Y  | Xerox Phaser 6180/6180MFP                               | 6000  | Y  | 6  | NEW |
| 146 | NT-CX6500XBK | Xerox<br>106R01597     | Xerox phaser 6500n/6500dn , WorkCentre 6505n/6505dn MFP | 3000  | BK | 18 | NEW |
| 147 | NT-CX6500XC  | Xerox<br>106R01594     | Xerox phaser 6500n/6500dn , WorkCentre 6505n/6505dn MFP | 2500  | C  | 18 | NEW |
| 148 | NT-CX6500XM  | Xerox<br>106R01595     | Xerox phaser 6500n/6500dn , WorkCentre 6505n/6505dn MFP | 2500  | M  | 18 | NEW |
| 149 | NT-CX6500XY  | Xerox<br>106R01596     | Xerox phaser 6500n/6500dn , WorkCentre 6505n/6505dn MFP | 2500  | Y  | 18 | NEW |
| 150 | NT-CX6010BK  | Xerox<br>106R01630     | Xerox phaser 6000 / 6010 / 6010n                        | 2000  | BK | 24 | NEW |
| 151 | NT-CX6010C   | Xerox<br>106R01627     | Xerox phaser 6000 / 6010 / 6010n                        | 1000  | C  | 40 | NEW |
| 152 | NT-CX6010M   | Xerox<br>106R01628     | Xerox phaser 6000 / 6010 / 6010n                        | 1000  | M  | 40 | NEW |
| 153 | NT-CX6010Y   | Xerox<br>106R01629     | Xerox phaser 6000 / 6010 / 6010n                        | 1000  | Y  | 40 | NEW |

|     | A                        | B                           | C  | D     | E  | F  | G          |
|-----|--------------------------|-----------------------------|--|-------|----|----|------------|
| 1   | GG nr                    | OEM nr                      | Printer Models   | Sider |    | Pk |            |
| 154 |                          |                             | <b>Canon</b>   |       |    |    |            |
| 155 | NT-C0L50                 | Canon L50 / Cartridge M     | Canon PC1210D/1230D/1270D  | 5000  | BK | 6  | <b>NEW</b> |
| 156 | NT-C0E40 (E30/E16)       | Canon E16/E20/E30/E31/E40   | Canon PC200/ 210/ 220/ 230/ 310/ 330/ 320/ 325/ 330L/ 355/ 400/ 420/ 425/ 430/ 530/ 550/ 920/ E16/ E20/ FC220;Canon PC300/ 310/ 320/ 325/ 330/ 330L/ 400/ 420/ 430/ 530/ 550/ 710/ 720/ 740/ 745/ 770/ 790/ 795/ 920/ 921/ 950/ 980/ E40 Canon FC 220/270/290/ | 4000  | BK | 6  | <b>NEW</b> |
| 157 | NT-C2612 (Cartridge 703) | Canon G303/G703/HP2612      | Canon LBP-2900/3000 HP LaserJet 1010/1012/1015/ 1020/ 3015/3020/3030   | 2000  | BK | 12 | <b>NEW</b> |
| 158 | NT-C0FX9 (FX10)          | Canon FX9/FX10              | Canon FAX-L100 Canon i-SENSYS MF4150 Canon Image Class MF4150 Canon Satera MF4120  | 2000  | BK | 12 | <b>NEW</b> |
| 159 | NT-C0106 (Canon 706)     | Canon Cartridge 706         | Canon MF6530/6550  | 5000  | BK | 6  | <b>NEW</b> |
| 160 | NT-C0712                 | Canon Cartridge 712         | Canon LBP-3108/3180,LBP-3100/3010、LBP-3050/3150  | 1500  | BK | 12 | <b>NEW</b> |
| 161 | NT-CC120C (Canon 720)    | Canon Cartridge 720(Europe) | Canon i-SENSYS MF6680dn(Europe)  | 5000  | BK | 6  | <b>NEW</b> |
| 162 | NT-CC128C (Canon 728)    | Canon 728                   | Canon image CLASS MF4570dn/MF4420n/MF4412/MF4580/MF4430/MF4450/MF4410/MF4580dn   | 2100  | BK | 12 | <b>NEW</b> |



|     | A                     | B   | C  | D     | E  | F  | G          |
|-----|-----------------------|---|--|-------|----|----|------------|
| 1   | GG nr                 | OEM nr  | Printer Models   | Sider |    | Pk |            |
| 163 |                       |   | <b>Epson</b>   |       |    |    |            |
| 164 | NT-C6200XC            | Epson S050166                                 | Epson 6200   | 6000  | BK | 6  | <b>NEW</b> |
| 165 | NT-C6200C             | Epson S050167                                 | Epson 6200/ 6200L  | 3000  | BK | 6  | <b>NEW</b> |
| 166 | NT-C0187Y             | Epson S050187/S050191                         | Epson Color LaserJet C1100/C1100N/CX11/CX11N/CX11NF                  | 4000  | Y  | 16 | <b>NEW</b> |
| 167 | NT-C0188M             | Epson S050188/S050192                         | Epson Color LaserJet C1100/C1100N/CX11/CX11N/CX11NF                  | 4000  | M  | 16 | <b>NEW</b> |
| 168 | NT-C0189C             | Epson S050189/S050193                         | Epson Color LaserJet C1100/C1100N/CX11/CX11N/CX11NF                  | 4000  | C  | 16 | <b>NEW</b> |
| 169 | NT-C0190BK            | Epson S050190                                 | Epson Color LaserJet C1100/C1100N/CX11/CX11N/CX11NF                  | 4000  | BK | 16 | <b>NEW</b> |
| 170 | NT-CE1200XC           | Epson C13S050521/C13S050523(Return)           | Epson Aculaser M1200   | 3200  | BK | 6  | <b>NEW</b> |
| 171 |                       |   | <b>Konica Minolta</b>  |       |    |    |            |
| 172 | NT-CQ1650 BK          | Minolta A0V301N                               | Konica Minolta Magicolor 1600W/1650EN/1690MF                         | 2500  | BK | 6  | <b>NEW</b> |
| 173 | NT-CQ1650X C          | Minolta A0V30HN C/A0V30GN C                   | Konica Minolta Magicolor 1600W/1650EN/1690MF                         | 2500  | C  | 6  | <b>NEW</b> |
| 174 | NT-CQ1650X Y          | Minolta A0V305N Y/A0V306N                     | Konica Minolta Magicolor 1600W/1650EN/1690MF                         | 2500  | Y  | 6  | <b>NEW</b> |
| 175 | NT-CQ1650X M          | Minolta A0V30CN M/A0V30AN                     | Konica Minolta Magicolor 1600W/1650EN/1690MF                         | 2500  | M  | 6  | <b>NEW</b> |
| 176 |                       |   | <b>Lexmark</b>   |       |    |    |            |
| 177 | NT-PE230C (Universal) | Lexmark 22S0133 (E230/DELL 1700/ IBM 1412 )   | Lexmark E230/232/234/240/330/340/332/342/238 DALL 1700/1710 IBM 1412 | 3000  | BK | 6  | <b>NEW</b> |
| 178 | NT-PE330C (Universal) | Lexmark 12A8405 (E230/DELL 1700/ IBM 1412 )   | Lexmark E230/232/234/240/330/340/332/342/238 DALL 1700/1710 IBM 1412 | 6000  | BK | 6  | <b>NEW</b> |
| 179 | NT-PLE120C            | Lexmark 12035SA                               | Lexmark E120series   | 2000  | BK | 6  | <b>NEW</b> |
| 180 | NT-PLE250C            | Lexmark E250A21A /E250A21E E250A21L /E250A21P | Lexmark E250d/E350d/E352d  | 3500  | BK | 6  | <b>NEW</b> |
| 181 | NT-PX340XC            | Lexmark X340H21H                              | Lexmark X340/X340N/X342N   | 6000  | BK | 6  | <b>NEW</b> |
| 182 | NT-PLE350XC           | Lexmark E352H21A/ E250A11A                    | LEXMARK E350D/E352DN   | 9000  | BK | 6  | <b>NEW</b> |
| 183 | NT-PE450C             | Lexmark E450A21A/E450A11A                     | Lexmark E450DN   | 6000  | BK | 6  | <b>NEW</b> |
| 184 | NT-PE450XC            | Lexmark E450A21H/E450H11H                     | Lexmark E450DN   | 11000 | BK | 6  | <b>NEW</b> |
| 185 |                       |   | <b>Dell</b>  |       |    |    |            |

|     | A                     | B                              | C                                       | D     | E  | F  | G          |
|-----|-----------------------|--------------------------------|---|-------|----|----|------------|
| 1   | GG nr                 | OEM nr                         | Printer Models                          | Sider | Pk |    |            |
| 186 | NT-C1600X             | Dell 593-10082;310-5417(X5015) | Dell MFP Laser Printer 1600N            | 5000  | BK | 6  | <b>NEW</b> |
| 187 | NT-C1610X (Universal) | Dell 593-10094/ML-1610         | Dell 1100                               | 3000  | BK | 6  | <b>NEW</b> |
| 188 | NT-C1815XC            | Dell 310-7945/PF658            | Dell 1815 dn                            | 5000  | BK | 6  | <b>NEW</b> |
| 189 | NT-P1720C             | Dell 310-8706/310-8708         | Dell laser 1720/1720N                   | 3000  | BK | 6  | <b>NEW</b> |
| 190 | NT-P1720XC            | Dell 310-8707/310-8709         | Dell laser 1720/1720N                   | 6000  | BK | 6  | <b>NEW</b> |
| 191 | NT-C2335C             | Dell 330-2208                  | Dell 2335DN Multifunction Laser Printer | 3000  | BK | 6  | <b>NEW</b> |
| 192 | NT-C2335XC            | Dell 330-2209                  | Dell 2335DN Multifunction Laser Printer | 6000  | BK | 6  | <b>NEW</b> |
| 193 | NT-CD2355XC           | DELL 331-0611                  | DELL 2355DN                             | 10000 | BK | 6  | <b>NEW</b> |
| 194 | NT-C5361Y             | Dell 593-10063/5361            | Dell color laser printer 3100cn         | 4000  | Y  | 16 | <b>NEW</b> |
| 195 | NT-C5362BK            | Dell 593-10067/5362            | Dell color laser printer 3000/3100cn    | 4000  | BK | 16 | <b>NEW</b> |
| 196 | NT-C5363M             | Dell 593-10062/5363            | Dell color laser printer 3100cn         | 4000  | M  | 16 | <b>NEW</b> |
| 197 | NT-C5364C             | Dell 593-10061/5364            | Dell color laser printer 3100cn         | 4000  | C  | 16 | <b>NEW</b> |
| 198 | NT-C5737Y (Universal) | Dell 310-5737                  | Dell Color Laser Printer 3100cn         | 2000  | Y  | 16 | <b>NEW</b> |
| 199 | NT-C5738M (Universal) | Dell 310-5738                  | Dell Color Laser Printer 3100cn         | 2000  | M  | 16 | <b>NEW</b> |
| 200 | NT-C5739C (Universal) | Dell 310-5739                  | Dell Color Laser Printer 3100cn         | 2000  | C  | 16 | <b>NEW</b> |
| 201 | NT-C0052BK            | Dell KU052BK                   | Dell Color Laser 1320C                  | 2000  | BK | 18 | <b>NEW</b> |
| 202 | NT-C0053C             | Dell KU0053C                   | Dell Color Laser 1320C                  | 2000  | C  | 18 | <b>NEW</b> |
| 203 | NT-C0054Y             | Dell KU054Y                    | Dell Color Laser 1320C                  | 2000  | Y  | 18 | <b>NEW</b> |
| 204 | NT-C0055M             | Dell KU055M                    | Dell Color Laser 1320C                  | 2000  | M  | 18 | <b>NEW</b> |
| 205 | NT-C2130XBK           | Dell 330-1389                  | Dell Color Laser 2130CN/2135CN          | 2500  | BK | 18 | <b>NEW</b> |
| 206 | NT-C2130XC            | Dell 330-1390                  | Dell Color Laser 2130CN/2135CN          | 2500  | C  | 18 | <b>NEW</b> |
| 207 | NT-C2130XM            | Dell 330-1391                  | Dell Color Laser 2130CN/2135CN          | 2500  | Y  | 18 | <b>NEW</b> |
| 208 | NT-C2130XY            | Dell 330-1392                  | Dell Color Laser 2130CN/2135CN          | 2500  | M  | 18 | <b>NEW</b> |
| 209 | NT-C3110XBK           | Dell 3110 BK (593-10169)       | Dell 3110cn Dell MFP 3115cn             | 8000  | BK | 6  | <b>NEW</b> |
| 210 | NT-C3110XC            | Dell 3110 C (593-10166)        | Dell 3110cn Dell MFP 3115cn             | 8000  | C  | 6  | <b>NEW</b> |
| 211 | NT-C3110XM            | Dell 3110 M (593-10167)        | Dell 3110cn Dell MFP 3115cn             | 8000  | M  | 6  | <b>NEW</b> |
| 212 | NT-C3110XY            | Dell 3110 Y (593-10168)        | Dell 3110cn Dell MFP 3115cn             | 8000  | Y  | 6  | <b>NEW</b> |
| 213 | NT-C3010BK            | Dell 593-10154(BK)             | Dell 3010cn                             | 2000  | BK | 16 | <b>NEW</b> |
| 214 | NT-C3010C             | Dell 593-10155(C)              | Dell 3010cn                             | 2000  | C  | 16 | <b>NEW</b> |
| 215 | NT-C3010M             | Dell 593-10157(M)              | Dell 3010cn                             | 2000  | M  | 16 | <b>NEW</b> |
| 216 | NT-C3010Y             | Dell 593-10156(Y)              | Dell 3010cn                             | 2000  | Y  | 16 | <b>NEW</b> |
| 217 | NT-C3130XBK           | Dell 330-1198 BK               | Dell 3130CN                             | 9000  | BK | 6  | <b>NEW</b> |
| 218 | NT-C3130XC            | Dell 330-1199 BK               | Dell 3130CN                             | 9000  | C  | 6  | <b>NEW</b> |
| 219 | NT-C3130XM            | Dell 330-1200 BK               | Dell 3130CN                             | 9000  | M  | 6  | <b>NEW</b> |

|     | A            | B                                 | C   | D     | E  | F  | G   |
|-----|--------------|-----------------------------------|---|-------|----|----|-----|
| 1   | GG nr        | OEM nr                            | Printer Models  | Sider |    | Pk |     |
| 220 | NT-C3130XY   | Dell 330-1201 BK                  | Dell 3130CN   | 9000  | Y  | 6  | NEW |
| 221 | NT-CD1235K   | Dell 593-10493                    | Dell 1230c Color Laser Printer;Dell 1235CN Multifunction Colour Laser Printer | 1500  | BK | 6  | NEW |
| 222 | NT-CD1235c   | Dell 593-10494                    | Dell 1230c Color Laser Printer;Dell 1235CN Multifunction Colour Laser Printer | 1000  | C  | 6  | NEW |
| 223 | NT-CD1235m   | Dell 593-10495                    | Dell 1230c Color Laser Printer;Dell 1235CN Multifunction Colour Laser Printer | 1000  | M  | 6  | NEW |
| 224 | NT-CD1235y   | Dell 593-10496                    | Dell 1230c Color Laser Printer;Dell 1235CN Multifunction Colour Laser Printer | 1000  | Y  | 6  | NEW |
| 225 | NT-CD2150XBK | Dell593-11040                     | Dell 2150cn, 2150cdn, multifunction 2155cn, MFP 2155cdnMFP                    | 3000  | BK | 18 | NEW |
| 226 | NT-CD2150XC  | Dell593-11041                     | Dell 2150cn, 2150cdn, multifunction 2155cn, MFP 2155cdnMFP                    | 2500  | C  | 18 | NEW |
| 227 | NT-CD2150XM  | Dell593-11033                     | Dell 2150cn, 2150cdn, multifunction 2155cn, MFP 2155cdnMFP                    | 2500  | M  | 18 | NEW |
| 228 | NT-CD2150XY  | Dell593-11037                     | Dell 2150cn, 2150cdn, multifunction 2155cn, MFP 2155cdnMFP                    | 2500  | Y  | 18 | NEW |
| 229 | NT-CD1250XBK | Dell 331-0778/331-0779/592-11592  | Dell 1250c 、 1350cnw , 1355 Cn color printer                                  | 2000  | BK | 24 | NEW |
| 230 | NT-CD1250XC  | Dell 331-0777/593-11021/592-11591 | Dell 1250c 、 1350cnw , 1356 Cn color printer                                  | 1400  | C  | 40 | NEW |
| 231 | NT-CD1250XM  | Dell 331-0780/593-11018/592-11589 | Dell 1250c 、 1350cnw , 1357 Cn color printer                                  | 1400  | M  | 40 | NEW |
| 232 | NT-CD1250XY  | Dell 331-0779/593-11019/592-11590 | Dell 1250c 、 1350cnw , 1358 Cn color printer                                  | 1400  | Y  | 40 | NEW |
| 233 |              |                                   | <b>Oki</b>  |       |    |    |     |
| 234 | NT-F4200     | OKI 42103001                      | OKI B4100/4200/4300/4250/4350/4350n   | 2500  | BK | 30 | NEW |
| 235 | NT-C3400K    | OKI 43459304/43459408             | OKI C3400N/C3300 / C3450 / C3600 ( not yet C3520 MFP / C3530 MFP )            | 2500  | BK | 36 | NEW |
| 236 | NT-C3400C    | OKI 43459303/43459407             | OKI C3400N/C3300 / C3450 / C3600 ( not yet C3520 MFP / C3530 MFP )            | 2000  | C  | 36 | NEW |
| 237 | NT-C3400M    | OKI 43459302/43459406             | OKI C3400N/C3300 / C3450 / C3600 ( not yet C3520 MFP / C3530 MFP )            | 2000  | M  | 36 | NEW |
| 238 | NT-C3400Y    | OKI 43459301/43459405             | OKI C3400N/C3300 / C3450 / C3600 ( not yet C3520 MFP / C3530 MFP )            | 2000  | Y  | 36 | NEW |
| 239 | NT-C5600BK   | OKI 43381908                      | OKI C5600(Europe)   | 6000  | BK | 24 | NEW |
| 240 | NT-C5600C    | OKI 43381907                      | OKI C5600(Europe)   | 5000  | C  | 24 | NEW |
| 241 | NT-C5600M    | OKI 43381906                      | OKI C5600(Europe)   | 5000  | M  | 24 | NEW |
| 242 | NT-C5600Y    | OKI 43381905                      | OKI C5600(Europe)   | 5000  | Y  | 24 | NEW |
| 243 | NT-C5650BK   | OKI 43865708                      | OKI C5650(Europe)   | 8000  | BK | 24 | NEW |
| 244 | NT-C5650C    | OKI 43872307                      | OKI C5650(Europe)   | 2000  | C  | 24 | NEW |
| 245 | NT-C5650M    | OKI 43872306                      | OKI C5650(Europe)   | 2000  | M  | 24 | NEW |
| 246 | NT-C5650Y    | OKI 43872305                      | OKI C5650(Europe)   | 2000  | Y  | 24 | NEW |
| 247 | NT-C5850BK   | OKI 43865724                      | OKI C5950(Europe) Color Laser Printer   | 8000  | BK | 24 | NEW |
| 248 | NT-C5850C    | OKI 43865723                      | OKI C5950(Europe) Color Laser Printer   | 6000  | C  | 24 | NEW |
| 249 | NT-C5850M    | OKI 43865722                      | OKI C5950(Europe) Color Laser Printer   | 6000  | M  | 24 | NEW |

|     | A                         | B                                 | C   | D     | E  | F  | G   |
|-----|---------------------------|-----------------------------------|---|-------|----|----|-----|
| 1   | GG nr                     | OEM nr                            | Printer Models  | Sider |    | Pk |     |
| 250 | NT-C5850Y                 | OKI 43865721                      | OKI C5950(Europe) Color Laser Printer   | 6000  | Y  | 24 | NEW |
| 251 | NT-C5100XUBK              | OKI 41963004                      | OKI C5200/5300  | 5000  | BK | 12 | NEW |
| 252 | NT-C5100XUC               | OKI 41963003                      | OKI C5200/5300  | 5000  | C  | 12 | NEW |
| 253 | NT-C5100XUM               | OKI 41963002                      | OKI C5200/5300  | 5000  | M  | 12 | NEW |
| 254 | NT-C5100XUY               | OKI 41963001                      | OKI C5200/5300  | 5000  | Y  | 12 | NEW |
| 255 |                           |                                   | <b>Kyocera</b>  |       |    |    |     |
| 256 | NT-FTK17                  | Kyocera TK17/TK18/TK100           | Kyocera FS1010/FS1118MFP/KM 1500  | 6000  | BK | 6  | NEW |
| 257 | NT-FTK18U                 | Kyocera TK17/TK18/TK100           | Kyocera FS1010/FS1118MFP/KM 1500  | 7200  | BK | 6  | NEW |
| 258 | NT-FTK110                 | Kyocera TK-110                    | Kyocera FS-720/820/920  | 6000  | BK | 6  | NEW |
| 259 | NT-FTK120                 | Kyocera TK-120                    | Kyocera FS-1030   | 7200  | BK | 6  | NEW |
| 260 | NT-FKTK130                | Kyocera TK-130                    | Kyocera FS-1300D/1350/1028MFP/1128MFP   | 7000  | BK | 12 | NEW |
| 261 |                           |                                   | <b>Tromler</b>  |       |    |    |     |
| 262 | NT-D0350 (DR2000)         | Brother DR-2000 Drum Unit         | Brother HL-2040/2070/2460 Brother DCP-7020 Brother MFC-7220/7225/7420/7820 Brother intellifax 2820/2920 FUJII XEROX Docuprint 203A/204A   | 12000 | BK | 8  | NEW |
| 263 | NT-D0520 (DR3100)         | Brother DR-3100 DRUM UNIT         | Brother HL-5240 / 5250DN / 5250DNT / 5280DW   | 25000 | BK | 8  | NEW |
| 264 | NT-D0360 (DR2100)         | Brother DR-2100 DRUM UNIT         | Brother HL-2140/2170W/2150N,MFC-7840W/MFC-7440N/MFC-7450/7340/7320 , DCP-7040/7030 LJ2200、 LJ2250、 LJ2250N  | 12000 | BK | 8  | NEW |
| 265 | NT-DB420                  | Brother DR-2200                   | Brother HL-2240/2240D/2250DN/2270DW/MFC-7360/MFC-7460DN/MFC-7860D/DCP-7060/DCP-7065DN   | 12000 | BK | 8  | NEW |
| 266 | NT-D0510U (DR7000 DR3000) | Brother DR3000 / DR7000 DRUM UNIT | Brother HL-1650/1670N/1850/1870N/5030/5040/5050/5070N/5140/5150D/5150DLT/5170DN/5130 Brother MFC -8420/8820D/8820DN/8220/8440/8840D/8840DN Brother DCP-8020/8025D/8040/8045D  | 20000 | BK | 8  | NEW |
| 267 | NT-D0400 (DR6000)         | Brother DR6000 / DR6050 DRUM UNIT | Brother MFC -8300/8500/8600/8700/9600/9650/9650N/9660/9660N/9700/9750/9750LT/9760/9800/9870/9880/9870NLT/9880N / Brother FAX-8350P/8750P/8750PNLT Brother DCP-1200/1400 Brother HL-1030/1230/1240/1250/1270N/1435/1440/1450/1470N/P 2500 Brother intellifax 4750/4750e/5750/5750e | 20000 | BK | 8  | NEW |
|     |                           |                                   | Lenovo LJ2312/2500/6212/6112  |       |    |    |     |

|     | A                    | B  | C   | D     | E  | F | G          |
|-----|----------------------|--|---|-------|----|---|------------|
| 1   | GG nr                | OEM nr   | Printer Models  | Sider | Pk |   |            |
| 268 | NT-D0620<br>(DR3200) | Brother DR3200<br>DRUM UNIT                                    | Brother HL-5340D/5350DN/5370DW/5380DN;DCP-8050DN/8080DN/8380DN/8480DN | 25000 | BK | 8 | <b>NEW</b> |
| 269 | NT-D1720<br>(DE250)  | Dell 310-8703,lexmark 44101706, IM 39V1645,E250X 22G DRUM UNIT | Dell 1720,LexmarkE250/350/352/450,IBM InfoPrint 1612/1622             | 30000 | BK | 8 | <b>NEW</b> |